



Ford Ranger XLT 98-00 2wd Performance 5.5 Kit

Upper Arm Hardware (1 Left Arm / 1 Right Arm)

8	Upper Arm Bushings (# 2587)
4	Inner Pivot Sleeves (# 1510.196.39)
4	Zerk Fittings
4	Grease Packets
2	5/8-18 x 4.5" G9 Bolts
4	5/8" SAE G8 Washers
2	5/8-18 Stover Nuts
4	1" x 5/8" Mis-alignment Spacers (# 040031)
2	UCA Bumpstops (# 60235)
2	3/8" SAE G8 Washers
2	3/8-16 Nyloc Nuts

Spindle Hardware (1 Left Spindle / 1 Right Spindle)

2	1/4-28 x 2" G8 Bolts
2	1/4-28 x 3/4" G8 Bolts
8	1/4" SAE G8 Washers
4	1/4-28 Stover Nuts

Misc. Hardware & Components

2	Bilstein 5100 front shocks (BE5-E675 or BE5-6210)
2	Ranger 98-11 5.5 Coil Springs
2	8" Limit Straps
2	Limit Strap Frame Tabs
4	1/2-13 x 1.25" G8 Bolts
8	1/2" SAE G8 Washers
4	1/2-13 Stover Nuts
1	Extended Front Brake Line Kit (# 130015)
4	8.5" Camburg 3C Stickers

Notes:

- 1) You must press out the OEM stock spindle pin/snout and press into the Camburg spindles. Aftermarket lift spindle pins will NOT work.
- 2) We recommend running a 31-33" tire on either a 15"-17" rim with a maximum backsparing of 4.75"
- 3) You must install the larger 11.25" OD front brake rotors that come on the 2001-2011 models.