



### Chevy Silverado 1500 99-06 2wd Performance 6.5 Kit

#### Upper Arm Hardware (1 Left Arm / 1 Right Arm)

---

8	Upper Arm Bushings (# 2587)
4	Inner Pivot Sleeves (#1510.196.39)
4	90 deg. Zerk Fittings
4	Grease Packets
2	5/8-18 x 4.5" G9 Bolts
4	5/8" SAE G8 Washers
2	5/8-18 Stover Nuts
4	1" x 5/8" tall Mis-alignment Spacers (#040031)

#### Spindle Hardware (1 Left Spindle / 1 Right Spindle)

---

2	1/4-28 x 1/2" G8 Bolts
4	1/4" SAE G8 Washers
2	1/4-28 Stover Nuts
2	1/4" Rubber Clamps (brake line)

#### Misc. Hardware & Components

---

1	Extended Front Brake Line Kit (# 230001)
2	Bilstein 5100 Front Shocks (24-185400 / BE5-6092)
2	Eibach Silverado 99-06 6.5 Coil Springs
2	10" Limit Straps
2	Limit Strap Lower Arm Mounts (1 left / 1 right)
4	1/2-13 x 1.25" G8 Bolts
8	1/2" SAE G8 Washers
4	1/2-13 Stover Nuts
6	3/8-24 x 1" G8 Bolts
12	3/8" SAE G8 Washers
6	3/8-24 Stover Nuts
4	8.5" Camburg Stickers

#### Notes:

---

**1) You MUST trim off the factory droop stop below the upper arm on the frame or damage WILL occur.**

2) We recommend running a 33"-35" tire on either a 16"-17" rim with a maximum backspacing of 4.75"

3) You will need to run fiberglass front fenders with 35" tires.

4) Limit strap mounts to front of lower arm and bolts to the front of the coil bucket using supplied hardware. We recommend welding the lower mount on for an easier installation.

5) The factory sway-bar will not be re-used as it limits wheel travel & articulation.