



Toyota Tacoma 16-20 Pre/4wd Long-Travel Kit [CAM-310101]

Bushing Upper Arm Hardware (1 Left Arm / 1 Right Arm)

8	Upper Arm Bushings
4	Inner Pivot Sleeves (7/8" OD X 9/16" ID X 2.335" OAL)
8	Large plated Washers
4	90 Degree Zerk Fittings (self tapping)
4	Grease Packets
2	M14 x 1.50 Nyloc Nuts
2	M14 Washers
4	10-32 x 3/4" SHCS Bolts
4	10-32 Nyloc Nuts
8	Stainless 10-32 Washers
4	Abs Wire Clamps
2	9/16-18 x 4" 12pt Bolts
2	9/16-18 Stover Lock Nuts
2	9/16" SAE G8 Washers
2	1.25" x 9/16" Recessed Uniball Spacers (top)(#960097)
2	1.25" x 9/16" Tapered Uniball Spindle Spacers (bottom)(#960100)

Lower Arm Hardware (1 Left Arm / 1 Right Arm)

4	Inner Pivot Uniball Spacers (long / 0.630" id)(rear mount)(#960262)
4	Inner Pivot Uniball Spacers (short / 0.825" id)(front mount)(#960263)
2	1/2-13 x 2.75" G8 Bolts
4	1/2" SAE G8 Washers
2	1/2-13 Stover Nuts

Misc. Hardware & Components

2	1.25" LCA Uniball Spindle Adaptors
4	M16 x 1.50 x 40mm SHCS Bolts
2	1.25" x 5/8" Recessed Uniball Spacers (top)(#960098)
2	1.25" x 5/8" Mis-alignment Uniball Spacers (bottom)(#960101)
2	MS21250-10040 5/8" 12pt Bolts
2	5/8 SAE G8 Washers
2	5/8-18 Stover Lock Nuts (gold)
2	10" Limit Straps
2	Limit Strap Frame Tabs
4	1/2-13 x 1.25" G8 Bolts
8	1/2" SAE G8 Washers
4	1/2-13 Stover Nuts
1	Extended Front Brake Line Kit (#330003)
2	M16 x 1.5 Steering Extensions (#960092)
2	Upper Coilover Mounting Plates
4	Weld-on Res Mounts (small)
2	1/2-13 x 4.5" G8 Bolts
4	1/2" SAE G8 Washers
2	1/2-13 Stover Nuts
6	3/8-24 x 1" G8 Bolts
12	3/8" SAE G8 Washers
6	3/8-24 Stover Nuts
4	8.5" Camburg Stickers

Notes:

- 1) When installing lower arm spindle uniball adaptors, make sure the snap ring is facing up and spacers are fully seated into the arm prior to tightening.
- 2) Use red loctite on all spindle adaptor bolts and nuts. Torque 5/8" 12pt bolt to 160 ft/lbs.
- 3) We recommend running a 33"-35" tire on either a 16" or 17" rim with a maximum backspacing of 4.75"
- 4) We recommend using a 16" x 600# coil, on the correct Fox or King 8" travel shocks. Shocks must have a 90 degree fitting on the top cap, a raised lower spring seat and 1.25" shock spacers. If you're using this kit with a lift spindle we recommend using a lighter rate 500# coil.
- 5) We recommend using 2.0 x 2"-2.5" bumpstops.
- 6) Fiberglass front fenders are required.