



Toyota Tundra 04-06 2wd/4wd Long-Travel Kit

Upper Arm Hardware (1 Left Arm / 1 Right Arm)

| | |
|---|-------------------------------------------------------|
| 8 | Upper Arm Bushings (#010030) |
| 4 | Inner Pivot Sleeves (7/8" OD X 9/16" ID X 2.335" OAL) |
| 8 | Large plated Washers (#970414) |
| 4 | 90 Degree Zerk Fittings (self tapping) |
| 4 | Grease Packets |
| 2 | M14 x 1.50 Nyloc Nuts |
| 2 | M14 Washers |
| 2 | 10-32 x 3/4" Steel SHCS Bolts |
| 2 | 10-32 Steel Nyloc Nuts |
| 4 | 10-32 Stainless Washers |
| 2 | Abs Wire Clamps |
| 2 | 5/8-18 x 4.5" G9 Bolts |
| 2 | 5/8-18 Stover Nuts |
| 2 | 1" x 5/8" Mis-alignment Spacers (top) (#040031) |
| 2 | Uniball Spindle Adaptors (bottom) (#960012) |
| 2 | Spindle Adaptor Snap Rings |

Lower Arm Hardware (1 Left Arm / 1 Right Arm) (Big Ball-joint)

| | |
|---|----------------------------------------------------------|
| 4 | Inner Pivot Uniball Front Mount Spacers (long) (#960034) |
| 4 | Inner Pivot Uniball Rear Mount Spacers (short) (#960035) |
| 2 | 1/2-13 x 2.5" G8 Bolts |
| 4 | 1/2 SAE G8 Washers |
| 2 | 12/-13 Stover Nuts |

Misc. Hardware & Components

| | |
|----|---------------------------------------------|
| 2 | 12" Limit Straps |
| 2 | Limit Strap Frame Tabs |
| 4 | 1/2-13 x 1.25" G8 Bolts |
| 8 | 1/2" SAE G8 Washers |
| 4 | 1/2-13 Stover Nuts |
| 1 | Extended Front Brake Line Kit (#330002) |
| 2 | M18 x 1.5 Steering Extensions (#960049) |
| 2 | Upper Coilover Mounting Plates |
| 2 | Coilover Remote Res. Frame Mounts (1L & 1R) |
| 2 | 1/2-13 x 4.5" G8 Bolts |
| 4 | 1/2" SAE G8 Washers |
| 2 | 1/2-13 Stover Nuts |
| 6 | 3/8-24 x 1" G8 Bolts |
| 12 | 3/8" SAE G8 Washers |
| 6 | 3/8-24 Stover Nuts |
| 4 | 8.5" Camburg Stickers |

Notes:

- 1) Grind the nubs that hang down from the lower ball-joint as it can scratch the powdercoat on the lower arms at full droop (extension).
- 2) Check upper arm clearance on the backside of the coil bucket. You may need to grind the edge back an 1/8".
- 3) We recommend running a 33"-34" tire on either a 16" or 17" rim with a maximum backspacing of 4.5"
- 4) We recommend using a 18" x 600# coil, on the correct Fox or King 8" travel shocks. Shocks must have a 90 degree fitting on the top cap, a flat lower spring seat and 1.25" shock spacers.
- 5) We recommend using 2.0 x 2"-2.5" bumpstops.
- 6) Fiberglass front fenders are required.