



Ford Ranger Edge/Sport 01-12 2wd Performance 6.0 Kit (single)

Upper Arm Hardware (1 Left Arm / 1 Right Arm)

8	Upper Arm Bushings (# 2587)
4	Inner Pivot Sleeves (# 1510.196.39)
4	90 Degree Zerk Fittings (self tapping)
4	Grease Packets
2	5/8-18 x 4.5" G9 Bolts
4	5/8" SAE G8 Washers
2	5/8-18 Stover Nuts
4	1" x 5/8" Tall Mis-alignment Spacers (# 040031)

Spindle Hardware (1 Left Spindle / 1 Right Spindle)

2	1/4-28 x 2" G8 Bolts
2	1/4-28 x 3/4" G8 Bolts
8	1/4" SAE G8 Washers
4	1/4-28 Stover Nuts

Misc. Hardware & Components

2	Bilstein 5100 front shocks (# 24-185523 BE5-6243) w/ T-bar installed (# E4-GV3-Z009A04)
4	5/16-18 x 1.25" G8 Bolts
8	5/16" SAE G8 Washers
4	5/16-18 Stover Nuts
2	10" Limit Straps
2	Limit Strap Frame Tabs
4	1/2-13 x 1.25" G8 Bolts
8	1/2" SAE G8 Washers
4	1/2-13 Stover Nuts
1	Extended Front Brake Line Kit (# 130007)
4	8.5" Camburg Stickers

Notes:

- 1) You must press out the OEM stock spindle pin/snout and press into the Camburg spindles. Aftermarket lift spindle pins will NOT work.
- 2) We recommend running a 31-33" tire on either a 15"-17" rim with a maximum backspacing of 4.75"
- 3) Make sure ABS wheel speed sensors and tone rings are clean from debris.