



## Ford Ranger Edge/Sport 01-12 2wd Performance 6.0 Kit (dual)

### Upper Arm Hardware (1 Left Arm / 1 Right Arm)

---

8	Upper Arm Bushings (# 2587)
4	Inner Pivot Sleeves (# 1510.196.39)
4	90 Degree Zerk Fittings (self tapping)
4	Grease Packets
2	5/8-18 x 4.5" G9 Bolts
4	5/8" SAE G8 Washers
2	5/8-18 Stover Nuts
4	1" x 5/8" Tall Mis-alignment Spacers (# 040031)

### Spindle Hardware (1 Left Spindle / 1 Right Spindle)

---

2	1/4-28 x 2" G8 Bolts
2	1/4-28 x 3/4" G8 Bolts
8	1/4" SAE G8 Washers
4	1/4-28 Stover Nuts

### Misc. Hardware & Components

---

4	Bilstein 5100 8" front shocks (# 33-185590   BE5-6252)
2	Upper Weld-on Shock Towers
2	Lower Weld-on Shock Mounts (1 left / 1 right)
4	1/2-13 x 5" G8 Bolts
2	10" Limit Straps
2	Limit Strap Frame Tabs
4	1/2-13 x 1.25" G8 Bolts
24	1/2" SAE G8 Washers
8	1/2-13 Stover Nuts
1	Extended Front Brake Line Kit (# 130007)
4	8.5" Camburg Stickers

### Notes:

---

- 1) You must press out the OEM stock spindle pin/snout and press into the Camburg spindles. Aftermarket lift spindle pins will NOT work.
- 2) We recommend running a 31-33" tire on either a 15"-17" rim with a maximum backspacing of 4.75"
- 3) Make sure ABS wheel speed sensors and tone rings are clean from debris.